

HOW TO TURN OFF THE AUTOMATICALLY UPDATE CHECK

Disable "Check Automatically" and "Allow Updates" (No matter if your printer firmware version has been to the latest, we suggest you to disable Allow Updates to prevent the firmware update automatically.)



HOW TO DOWNGRADE THE FIRMWARE

1. **Allow Downgrade** (If the printer's firmware version has been the latest 20221010, you are recommended to downgrade the firmware.)




2. After Downgrade, go to the website “<http://www.inktonerhelp.com/contents/65/19.html>” to select your printer model to download the old firmware to your computer.

Choose the printer model to download the old firmware.

Printer model	File name	File type	/
HP CF500 (HP 202) , CF540 (HP 203) series Printer firmware	W7 HP_Color_LaserJet_Pro_M254_dw_Printer_series_20200612	zip	Download
	W7 HP_LaserJet_Pro_M280_M281_Printer_series_20200612	zip	Download
	W10 HP_Color_LaserJet_Pro_M254_dw_Printer_series_20200612	zip	Download
	W10 HP_LaserJet_Pro_M280_M281_Printer_series_20200612	zip	Download
HP CF510 (HP 204) , CF530 (HP 205) series Printer firmware	W7 HP_LaserJet_M153_M154_Printer_series_20200612	zip	Download
	W7 HP_LaserJet_Pro_M180_M181_series_20200612	zip	Download
	W10 HP_LaserJet_M153_M154_Printer_series_20200612	zip	Download
	W10 HP_LaserJet_Pro_M180_M181_series_20200612	zip	Download

3. Open the old firmware package and select printer to update. And then click “SendFirmware” to start downgrade progress, which takes around 5 minutes. (connect printer and computer with USB cable)



4. The smile face means downgrade is successful and the printer can work normally with general supplies.

